

Hubbard-Hall Inc. • 563 South Leonard Street, Waterbury, CT 07608 • HubbardHall.com • 800-648-3412

Product Bulletin

Product Name: Ultrex AS 181 W Product Code: 2002074 Revision Date: June 29, 2020

Ultrex AS 181 W

Ultrex AS 181 W is a highly alkaline soak cleaner, formulated especially for steel and copper. Its formulation provides for excellent removal of oils and grease, preparing the base metal for additional processing in a wide range of finishing cycles.

Features & Benefits

Excellent emulsification	Dispenses and suspends soils
properties	
Rapid, efficient cleaning	Suitable for barrel, rack, and
in standard soak cleaning	mass finishing cycles.
cycles	

Physical Data

Appearance	Free flowing, off white powder
Odor	Slight
Dusty	No
Foaming tendency	Moderate
Maximum solubility	24 oz/Gal at 180°F (180 g/L at 82°C)

Product Profile

Caustic	Yes
Phosphate	Yes
Silicate	Yes
Chelates (EDTA, NTS types)	No

Hazard Classification

nazara Glacomoation	
DOT Hazard Class	8 (Corrosive Material)
DOT Shipping Name	Corrosive Solid, Basic Inorganic N.O.S.
UN Number	3262
Packing Group	II
Guide Number	154

^{*} contains Sodium Hydroxide & Sodium Metasilicate









Hubbard-Hall Inc. • 563 South Leonard Street, Waterbury, CT 07608 • HubbardHall.com • 800-648-3412

Product Bulletin

Product Name: Ultrex AS 181 W Product Code: 2002074 Revision Date: June 29, 2020

Operating Conditions

	Range	Optimum
Concentration	8 – 16 oz/Gal (60 – 120 g/L)	12 oz/ Gal (90 g/L)
Temperature	140°F – 190° F (60°C – 88°C)	165° F (74°C)
Time	2 – 5 min	As required
Agitation	Solution movement or mild air	As required

Note: The high alkalinity of Ultrex AS 181 W solutions may darken or etch brass parts somewhat. Aluminum and zinc parts will be severely etched. Your Hubbard-Hall Technical Representative will recommend a suitable soak cleaner for these sensitive metals.

Equipment

Tank	Mild steel, reinforced polypro, or fiberglass
Heater	Steel coil, steel immersion type, steam fed, or gas fired
Ventilation	Mechanical to maintain levels below permissible
	exposure limits
Agitation	Stirrer, pump, work movement, or mild air

Solution make up

DANGER!! Ultrex AS 181 W contains Sodium Hydroxide. Consult Ultrex AS 181 W SDS sheet before handling this product. It should be handled with all the safety precautions associated with Sodium Hydroxide.

Be sure the process tank has been drained and cleaned. Fill to within two thirds of final operating volume with clean, warm water (100°F to 120°F, 38°C to 49°C). With good solution stirring, gradually add the required amount of Ultrex AS 181 W.

Rapid additions may result in localized boiling and spattering!

After the required amount of Ultrex 181 W has been added and dissolved, adjust final solution operating volume and temperature.

In mass finishing applications, add the parts and optional media. Fill the barrel with the preferred amount of cold or warm water (see page 1). Slowly add the required amount of Ultrex AS 181 W. Process the parts as required.

The surfactants and detergents are consumed in the cleaning process by emulsifying oils and grease. Alkaline components are used up in the cleaning process, such as by saponifying fatty acids. Drag out of the cleaner bath also depletes these active components. Regular maintenance additions of Ultrex AS 181 W are recommended to replenish the bath. This can be accomplished by observing quality of cleaning and making









Hubbard-Hall Inc. • 563 South Leonard Street, Waterbury, CT 07608 • HubbardHall.com • 800-648-3412

Product Bulletin

Product Name: Ultrex AS 181 W Product Code: 2002074 Revision Date: June 29, 2020

appropriate additions per requirements of the process. Alternatively, the cleaner bath can be analyzed to determine actual concentration of Ultrex AS 181 W and the required addition of product to restore the balanced ratio of all the cleaner components.

Process suggestions

Ultrex AS 181 W is a highly emulsifying soak cleaner. On cooling, some of the oils will be released. Therefore, skimming the cleaner to remove oils is recommended. Solutions of Ultrex AS 181 W are also compatible with coalesces and oil removal filters. At some point during the bath life, the buildup of oil and grease contaminants will effectively saturate it, beyond which maintenance additions or filtration will not maintain desired performance. When this occurs, the cleaner should be dumped and a fresh solution prepared. The Technical Center or your Hubbard Hall Inc. sales representative will be glad to help determine optimum bath life.

Hexavalent chromium contamination (only 30 ppm) will also shorten the cleaner bath service life. Additions of Enerox Chrome Reducer CER will efficiently reduce chrome to its trivalent state, precipitating it as CrIII Hydroxide, thereby extending cleaner life. Because of its free rinsing characteristics, Ultrex AS 181 W is particularly suited for systems where rinsing facilities are marginal. Ultrex AS 181 W is soap free. Therefore, no residues are left on cleaned surfaces. With proper post rinsing, parts entering the electro cleaner should be water break free.

Titration Method

- 1. Pipette a 5 mL sample of the cleaner bath into a 250 mL Erlenmeyer flask.
- 2. Add 50 to 100 mL of clean water and swirl to mix well.
- 3. Add 2 to 4 drops of Phenolphthalein indicator to develop a pink solution color.
- 4. Titrate with 0.5 N Hydrochloric Acid just until the pink color has been discharged.
- 5. Record mL used.

Calculation

Concentration (oz/Gal) = $mL 0.5 N HCl \times 0.8$

Test Kit Method

- 1. Fill test bottle ¼ full of water.
- 2. Using syringe provided, add ½ mL of Ultrex AS 181 W solution.
- 3. Add 5 to 10 drops Phenolphthalein indicator.
- 4. Add 0.72 N Hydrochloric Acid, while mixing the solution until solution turns from pink to clear.
- 5. Record the number of drops used.

Calculation

Concentration (oz/Gal) = # Drops 0.72 N HCl x 0.36









Hubbard-Hall Inc. • 563 South Leonard Street, Waterbury, CT 07608 • HubbardHall.com • 800-648-3412

Product Bulletin

Product Name: Ultrex AS 181 W Product Code: 2002074 Revision Date: June 29, 2020

Waste Disposal

Ultrex AS 181 W and it's working solutions are alkaline. They may be neutralized with acid to meet local POTW or municipal effluent discharge requirements. Sludges and oils should be separated out before discharge. Spent Ultrex AS 181 W solutions may contain dissolved metals from the cleaning process. Therefore, additional treatment of the solution may be required to meet discharge requirements.

Caution

Please read and understand the Ultrex AS 181 W Safety Data Sheet before handling and using this product.

WARRANTY: THE QUALITY OF THIS PRODUCT IS GUARANTEED ON SHIPMENT FROM OUR PLANT. IF THE USE RECOMMENDATIONS ARE FOLLOWED, DESIRED RESULTS WILL BE OBTAINED. SINCE THE USE OF OUR PRODUCTS IS BEYOND OUR CONTROL, NO GUARANTEE EXPRESSED OR IMPLIED IS MADE AS TO THE EFFECTS OF SUCH USE, OR THE RESULTS TO BE OBTAINED.

Our people. Your problem solvers.

For more information on this process please call us at 1-800-648-3412

or techservice@hubbardhall.com











